



OMNIKEY 5321 CL SAM

SAM/SIM CARD INSERTION

JANUARY , 2010

Version 1.01



Copyright

© 2010 HID Global Corporation. All rights reserved.

Version History

Date	Author	Description	Document Version
01/14/10	MP	Initial version	1.00
01/22/10	GW	Updated description	1.01

Contents

1	Introduction	3
2	SIM/SAM insertion	4

1 Introduction


This manual describes how to insert a SAM/SIM card into the OMNIKEY 5321 CL SAM.

Technical problems or questions:

<http://support.hidglobal.com>


2 SIM/SAM insertion

- Turn the reader that you can see the paper label.
- Open the SAM door as shown on Pic. 1 by pressing the small tongue marked by the green arrow.




Pic. 1

- move the metal locking as shown on Pic. 2:



Pic. 2

- open the hinge as shown on Pic. 3:




Pic. 3

- insert the card into the guidance in the direction shown on Pic. 4:



Pic. 4

- close the hinge and lock it as shown on Pic. 5:



Pic. 5

- close the cover



Pic. 6